

## umicore

# RHODUNA® 275 Black



### Pen rhodium plating for black bright coatings

With RHODUNA<sup>®</sup> 275 Black, selective rhodium plating is possible with a pen plating unit. Small surface elements of components are rhodium-plated using direct current and by wiping contact with the tip of the pen. The process is mainly used to apply decorative patterns to jewelry.

RHODUNA® 275 Black deposits bright and anthracite to black coatings. Depending on the voltage, values in the L\*a\*b\* color space of 61.0 / 1.1 / 4.0 (at 10 V) are possible, while providing typical coating thicknesses of around 0.1  $\mu$ m. RHODUNA® 275 Black is formulated to deliver fast coverage speed and high deposition efficiency.

The electrolyte can also be used for rack operation.



### Advantages

- Bright anthracite to black rhodium coatings
- Uniform coating thickness
- Crack-free up to 0.1 µm
- Easy handling
- Fast coverage speed
- High deposition rate

### Applications

- Jewelry
- Watches
- Writing implements
- Spectacle frames
- Fittings

# RHODUNA® 275 Black

## **TECHNICAL SPECIFICATIONS**

Electrolyte characteristics pen plating	
Electrolyte type	Strongly acidic
Metal content	2 g Rh / 100 ml
pH value	< 1
Operating temperature	Room temperature (20 - 40 °C)
Voltage	8 - 10 volts (max. 12 volts)
Deposition speed	Up to 0.1 µm/min

#### **Coating characteristics** Rhodium Coating Purity 99.9 wt.% Rh anthracite to black Colour of deposit L\*a\*b\* color range: 61.0 / 1.1 / 4.0 (at 10 V) Brightness Bright, brilliant Max. coating thickness approx. 0.1 µm Hardness of deposit approx. 600 HV HV 0.015 (Vickers) approx. values Density of the coating approx. 12 g/cm<sup>3</sup>

### Electrolyte characteristics rack operation

Electrolyte type	Strongly acidic
Metal content	2 g Rh / 100 ml
pH value	< 1
Operating temperature	Room temperature (20 - 30 °C)
Current density	1.5 (0.5 - 3.0) A/dm <sup>2</sup>
Deposition speed	approx. 0.05 $\mu m$ at 2.0 A/dm²
Anodes	Platinized titanium, e.g. PLATINODE® coated with 2.5 µm of Platinum

### YOUR CONTACT

Do you have a specific question or would you like a no-obligation quote calculation? Our specialist will be happy to help you with any technical questions you might have.



Markus Legeler Manager Sales International

Mail: markus.legeler@eu.umicore.com

Phone: +49 (0) 7171 607 - 204



The information and statements contained herein are based on our experience in the fields of research and applied technology and are believed to be accurate at the time of publication, but - unless agreed in writing - we make no warranty with respect thereto, including but not limited to any results to be obtained. This product information sheet in the English language prevails any translation.

mds.umicore.com